




Brilliant Aiming Solutions™



Trijicon® Dovetail Optics Mount

Quick Reference Card

Components




- A: Sealing Plate
- B: Mount
- C: Socket Set Screws
- D: Optic Mounting Screws

Recommended torque:
Trijicon RMR[®] cc - 18in-lbs
Trijicon RMR[®] - 15in-lbs
Trijicon SRO[®] - 15in-lbs

Installation

▲ WARNING: Ensure firearm is UNLOADED with the chamber open.

Step 1. Remove the slide from the pistol. Using a press, install the mount into the slide dovetail making sure it's centered on the slide. (Gunsmith installation recommended)



Installation (continued)


Step 2. If installing a battery operated optic, install the battery into the sight so that the "+" is facing you as shown. (Note: Failure to install the battery properly will damage the contacts and the unit will not operate)

Note: Please reference optic manual for additional details on proper battery installation



Step 3. Install the two socket set screws into the threaded holes. Tighten them down until the set screws are recessed below the face of the mount and snug, do not over tighten.

Note: Screws will be difficult to tighten



Installation (continued)

Step 4. Install the seal plate. With the seal plate installed, the RMR and RMRcc can be submerged up to 66 ft. for at least one hour without leakage.

Note: A seal plate is not required if mounting a Trijicon SRO



Step 5. Install sight – use the locating tabs on the sight and mount to determine the correct orientation and make sure the sight is fully seated (the optic should snap down and sit flush on the mount). Install the 2 Mount Screws supplied with the mount (Only use screws supplied with this mount).



Specifications subject to
change without notice
©2020 Trijicon, Inc.
PML6001-1 Rev(1) 0620

Trijicon, Inc.
49385 Shafer Avenue
P.O. Box 930059
Wixom, MI 48393

1-800-338-0563
248-960-7700

Trijicon.com